

- #1. Align base plate behind bumper and saddlebag brackets.
- #2. Attach side bracket to hitch base plate with carriage bolts but do not tighten. The lip on the side plate goes under the base plate.
- #3. Install and tighten side plates. The included bolt goes in the uppermost hole
- #4. Tighten the side plates to the base plate.



Make sure the hitch is mounted properly and securely. The manufacturer is not responsible for accidents.  
Dick Litz  
Fremont Nebraska