

Suzuki LC1500 / C90 Hitch Installation Instructions

The helmet lock **MUST** be removed. If you have saddle bags you haven't seen this little jewel as it's been hidden.



Attach the left and right side plates, using the 8mm x75mm bolts (included) if you have saddlebags or 8mm x 55mm bolts (not included) if you do not have saddlebags. If you have a backrest, install the side plates between the fender struts and the backrest Do not tighten the bolts yet leave them loose!



Mount the bottom plate on top of the side plates using the 4 carriage bolts (included). You should be able to move the side plates enough to get the bottom plate to rest on the lips of the side plates if you left the bolts loose in step 2.



Now tighten the side plate bolts and the bottom plate bolts. Install the ball(not included).

