

## Yamaha Roadliner with Corbin bags Hitch Installation Instructions

Remove the saddlebags



Remove the 2 saddlebag bolts and the rear strut cover bolts.  
Place the hitch side plate behind the strut cover and replace the saddlebag bolts and the strut cover bolts. Repeat for the other side. Leave the bolts loose for now!



Place the 4 carriage bolts through the holes on the side plates and attach the base plate on the bottom side of the side plates and attach with the 4 locking nuts and washers.



Tighten the 4 carriage bolts then go back and tighten the side plate / saddlebag bolts. Replace the saddlebags. Insert the ball mount tube and secure it using the 1/2 inch bolt, nut and cotter pin, Tighten the nut and bolt with (2) 3/4 inch wrenches to eliminate all receiver rattle. Attach your trailer ball to the ball mount tube.

